

### AUTOALARM X3 MET AFSTANDSBEDIENING

#### Eerst lezen voordat u begint aan de montage!

AutoStyle is niet verantwoordelijk voor vervolgschade die voortvloeit uit verkeerde montage!

#### X3 Snoerloze Aanstekerplug Sensor D.I.Y Alarm

##### 1. Inhoud:

1 passende aanstekerplug snoerloze sensor, (detecteert het volgende: open deuren, open kofferbak, gebroken ruiten & grote schokken), 1 module, 2 zenders.

##### 2. Installatie:

a. Schroef de Sirene op een plek onder de motorkap. Sluit de rode en zwarte draad van de sirene aan op de accu. Zorg ervoor dat de sirene iets naar beneden wordt gemonteerd, zodat er minder kans is dat er water in komt. Zorg er tevens voor dat de sirene niet te dicht bij een hittebron of motor wordt gemonteerd.  
b. Draai de schakelaar van de sensor naar de ON positie. Deze kunt u dan in de 12 volts aanstekerplug pluggen, zodat de sensor zich kan opladen. LET OP. De sensor laad zich alleen op wanneer de motor draait.

##### 3. Werking:

(1) Grote knop van zender, (Vergrendelen & Ontgrendelen)

a. Door 1x op deze knop te drukken kunt u het systeem vergrendelen, (systeem zal 1x piepen). Door een 2e keer op de knop te drukken kunt u het systeem ontgrendelen, (systeem zal 2x piepen). Piept het systeem 4x dan is er tussentijds een schok geweest. U zult bovenstaande stappen dan nogmaals moeten herhalen.

Sluit u alle deuren, ramen en achterklep voordat u het systeem inschakelt. Indien dit niet het geval is zal het systeem niet worden ingeschakeld.

Indien 1 van bovenstaande delen niet goed aangesloten zijn, of als er een schok plaatsvindt, zal het systeem 3x 30 seconden piepen. Door 1x op de grote knop te drukken zal het piepen stoppen. Door nogmaals op de knop te drukken zal het systeem tevens ontgrendeld worden.

b. Nabijheid functie, (Automatisch ontgrendelen bij nadering van uw auto en automatisch vergrendelen bij het verlaten van de auto).

- Druk op de grote knop en houdt deze 2 seconden ingedrukt, totdat het LED lampje 4x knippert. Het LED lampje zal nu elke 2-3 seconden knipperen om aan te geven dat het systeem in werking is.

Dus wanneer u binnen het bereik van de ontvanger komt zal het systeem automatisch ontgrendeld worden. (Dit wordt aangegeven doordat het systeem dan 2x piept.

Indien u weer buiten het bereik van de ontvanger komt zal het systeem na 30 seconden weer vergrendeld worden.

- Indien de zender al eerder op de nabijheid functie is gezet, houdt dan de knop op de zender voor 2 seconden ingedrukt totdat het LED lampje uitgaat. Druk hierna 2x op de zender. Het LED lampje zal 3x knipperen en daarna uitgaan.

c. Zender & Aanstekerplug sensor code inlezen:

Nadat u de witte draad hebt aangesloten, (wordt gebruikt voor het code inlezen), dient u binnen 8 seconden de sensor te activeren. Dit kan doormiddel van het ernaar toe blazen of door 1x op de knop van de zender te drukken. Elke keer dat een code ingelezen wordt zal het systeem piepen naar de hoeveelheid codes die ingelezen worden. Er kunnen maximaal 4 codes ingelezen worden.

(2) Kleine knop van de zender:

- Indien de zender met een 2e knop is uitgerust, druk dan op deze knop (kleine), en houdt deze 2 seconden vast. Hiermee kan de paniek functie worden ingeschakeld.



- Druk 1x op de kleine knop en daarna op de grote knop om het systeem met een zachte piep te vergrendelen of te ontgrendelen.

##### 4 Optie schoksensoren en stroom blokkadesensoren

a. Nadat u het systeem bevestigd heeft dient u binnen 8 seconden tegelijkertijd op knop 1&2 te drukken. De sirene zal dan 7x piepen om aan te geven dat u zich in het menu bevindt.

b. Druk nu 1x op knop 2. Er zijn 4 verschillende menu's.

Hieronder staat waaruit u kunt kiezen:

- Mode 1 (1x piepen): Alleen schoksensoren
- Mode 2 (2x piepen): Alleen stroom blokkadesensoren
- Mode 3 (3x piepen): Schoksensoren en stroom blokkadesensoren
- Mode 4 (4x piepen): Uitgeschakeld.

c. Wanneer u het gewenste menu hebt geselecteerd dient u op knop 1 te drukken om dit op te slaan en het menu te verlaten.

##### 5 Schok sensor reactie gevoeligheid set-up.

(Alleen mogelijk wanneer schoksensoren ingeschakeld).

a. Druk binnen 8 seconden nadat het systeem is ontgrendeld tegelijkertijd op knop 1&2. De sirene zal 5x piepen om aan te geven dat u zich nu in het menu bevindt.

b. Druk 1x op knop 2 (kleine knop). De sirene zal piepen naar de hoogte van de gekozen gevoeligheid. Er zijn in totaal 8 niveaus.

Dus wanneer de sirene 3x piept, staat de gevoeligheid op niveau 3, enzovoort.

c. Gedurende u het niveau bepaalt kunt u tegen het voertuig duwen. De sirene zal 1x piepen wanneer het systeem geactiveerd wordt. Druk nu op knop 1 om dit niveau vast te leggen en het menu te sluiten. Indien u op knop 2 drukt zal het systeem naar een hoger niveau schakelen.

d. Vanaf de fabriek is de stroom blokkadesensoren op ON gezet. De schoksensoren gevoeligheid staat op niveau 4.

Indien er gedurende 20 seconden op geen van beide knoppen gedrukt wordt wanneer u zich in het menu bevindt, zal deze automatisch overschakelen naar de ontgrendelde mode.

### CAR ALARM X3 WITH REMOTE CONTROL

#### Read this before starting the installation!

AutoStyle is not responsible for consequential damages resulting from incorrect installation!

#### X3 Wireless Lighter Sensor D.I.Y. Alarm

##### 1. Including:

1 lighter shape wireless sensor (can detect door open, trunk open, glass broken & big shocking), 1 module, 2-pc transmitter

##### 2. Installation:

a. Screw the siren in the hood and connect the siren red & black wires to battery +12 volt & ground each. Please keep the siren a little downward to avoid the water goes in. Do not install the siren too near the engine or high temperature area.

ATTN: 1. Keep the small black antenna wire straight & away from the steel as can to have longer range.

2. The X3 only suit for the vehicle that come with good sealing of door & trunk when closed.

b. Turn the switch on the lighter sensor to On position, then plug into the 12 volt lighter socket for charging when ignition key is On.

##### 3. Operation:

(1) 1st (Big) Button of Transmitter: Arm/Disarm

a. Press this button once can arm the system (will chirp once) or disarm the system (will chirp twice or chirp 4 times if triggered before). Please close all the doors & trunk well before arm the system, otherwise the system will not be triggered.

The siren will sound 3 times 30 seconds for any door open/trunk open/glass broken/big shocking when armed. Press this button once can stop the sounding if siren is triggered and system will still keep armed, must press button once again to disarm the system. Remark: The lighter sensor can be hidden in the glove box or inside of car where still can detect the air flow when door of trunk is open (when not in charging) that still can be triggered if all the doors & trunk closed well when armed.

b. Proximity Function (Automatic disarm when approaching the car and automatic arm when left the car)

Press & hold this button over 2 seconds until the LED flash 4 times then Off that show the transmitter will transmit the code (LED will flash when transmitting) every 2~3 seconds.

So when you approach the car, the system will chirp twice and automatic disarm the system if the codes are correct. And will automatic arm the system 30 seconds after left the car (over the receiving range).

I Still can press this button to arm the system even within the range, and will be automatic disarmed when left the receiving range then approaching the car again. Or press this button to disarm the system within the range, and will automatic arm the system 30 seconds after left the car receiving range.

I If the transmitter set to proximity (Automatic) function before, press & hold the transmitter button over 2 seconds until the LED is Off, then press the transmitter twice, the LED will flash 3 times to show the proximity function is Off (transmitter LED will not flash every 2~3 seconds).

c. Transmitter & Lighter Sensor Code-Learning:

Within the 8 seconds after connected the white wire (code learning wire) to ground once, trigger the lighter sensor (toward the sensor blowing by mouth if sensor switch is on, or switch on the sensor from off) or press the transmitter button once can learn the sensor or transmitter code into the siren. Will chirp once if 1st code is learned, chirp twice for 2nd code and so on, max. total 4 sets code can be learned.

Suggest to learn all the lighter sensor & transmitter codes into the siren if to do the code-learning.

The code-learning will be end immediately after the last set 4th code learned.

(2) Small 2nd Button of Transmitter:

I If the transmitter comes with 2nd button, press & hold the 2nd (small) button over 2 second will trigger the siren sounding 10 seconds for PANIC function.



I Press the 2nd button once then press the 1st (big) button again can arm or disarm the system with small chirp.

##### 4. Option Shock Sensor and Voltage Drop Sensor

a. Within 8 seconds after arm the system, press button 1 & 2 at the same time, the siren will chirp 7 times to show the system as in sensor setting mode.

b. Press button 2 once, The siren will chirp accordingly for confirmation sensor setting, total four mode. For example, the one chirp indicating the mode 1.

- Mode 1 (1 chirp): Only shock sensor
- Mode 2 (2 chirps): Only voltage drop sensor
- Mode 3 (3 chirps): Shock sensor and Voltage drop sensor
- Mode 4 (4 chirps): OFF

c. Once you get the desired mode, just press button 1 to record and exit.

##### 5. Shock Sensor Trigger Sensitivity Setting

(only available when shock sensor enabled)

a. Within 8 seconds after disarming the system, press button 1&2 at the same time, the siren will chirp 5 times to show the system as in shock sensor trigger sensitivity setting mode.

b. Press button 2 once, The siren will chirp accordingly for confirmation the level setting, total 8 levels of shock trigger sensitivity. For example, the one chirp indicating the level 1. Level 8 is highest sensitivity.

c. While setting the shock trigger sensitivity, knock the vehicle, the siren will chirp once when the shock sensor can trigger the alarm. Then press button 1, the system will exit setting mode. And if you press button 2, system will shift to other level of trigger sensitivity setting. Once you get the desired shock trigger sensitivity, just press button 1 to record and exit shock sensor trigger sensitivity setting.

d. Voltage Drop Sensor factory preset at ON mode, Shock Sensor factory preset at 4 level.

During system setting mode, if no button is pressed over 20 seconds, the system will automatically return to the disarmed mode.